



OPTIONAL LARGE DIA. PNEUMATIC PRESSER WHEEL ASM.

LEFT TO RIGHT OPERATION AS SHOWN
RIGHT TO LEFT OPERATION OPPOSITE

GENERAL INFORMATION		MATERIALS	
NO.	DESCRIPTION	ITEM NO.	DESCRIPTION
1	ENGINE	100	100
2	ALTERNATOR	100	100
3	FUEL TANK	100	100
4	DRIVE SHAFT	100	100
5	REAR SUSPENSION	100	100
6	REAR AXLE	100	100
7	REAR WHEEL	100	100
8	FRONT SUSPENSION	100	100
9	FRONT AXLE	100	100
10	FRONT WHEEL	100	100
11	STEERING KNUCKLE	100	100
12	STEERING KNUCKLE	100	100
13	FRONT WHEEL	100	100
14	FRONT AXLE	100	100
15	FRONT WHEEL	100	100

800-051-D